

■ Additional sheet

Compliance with Low Voltage Directive 2014/35/EU

Since 21 June 2023, EN61800-5-1 2007 / A1 (2017) / A11 (2021) has been harmonized standard listed on the Directive 2014/35/EU (Low Voltage). This additional sheet is very important to use VF-nC3C inverter safely, prevent injury to yourself and other people around you as well as to prevent damage to property in the area. Thoroughly familiarize yourself with the symbols and indications shown in the VF-nC3C instruction manual (E6581975) and then continue to read this additional manual.

See web page
<https://www.toshiba-tips.co.jp/en/products/inverter/standard.html>
for EU Declaration of Conformity and VF-nC3C instruction manual.

 WARNING	
 Mandatory action	• Install proper short-circuit protective device between the power supply and the inverter (primary side). If proper short-circuit protective device is not installed, short circuit current cannot be shut down by inverter alone and it will result in fire. Integral solid state short circuit protection in the inverter does not provide branch circuit protection. Branch circuit protection must be provided in accordance with any local codes • Take into account the minimum required prospective short-circuit current of short-circuit protective device. If short circuit protective device does not work properly due to lower level short-circuit current, it will result in electric shock or fire. • Install the inverter into enclosure based on this manual, and install short-circuit protective device or power distribution devices based on the manufacturer manual. When they are installed with improper coordination, this will result in electric shock or fire.
 Connect an earth to ground	• The grounding wire must be connected securely. If the grounding wire is not securely connected, when the inverter has failure or earth leakage, this will result in electric shock or fire. This product has an increased leakage current > 3.5 mA. • Use a protective ground conductor with at least 10 mm² (AWG 6) or two protective ground conductors with the cross section of the conductors supplying the power terminals. Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment. Otherwise, it will result in electric shock.



PKR86021-01



WARNING



- Read this manual and VF-nC3C instruction manual before installing or operating the inverter unit. Otherwise, it will result in electric shock, fire and other injuries.



Electric
shock

- RISK OF ELECTRIC SHOCK -
- DANGEROUS VOLTAGE MAY EXIST FOR _15_MINUTES AFTER REMOVING POWER. It will result in electric shock.



CAUTION



Mandatory
action

- This product can cause a DC current in the PE conductor. Where a residual current operated protective device (RCD) is used for protection against electric shock, only an RCD of Type B is allowed on the supply side of this product. All upstream RCD, up to the supply transformer, shall be of Type B. If proper device above is not used, it can result in electric shock.

This additional manual includes the correction and additional information for [16.4] of E6581975 to comply with Low Voltage Directive 2014/35/EU under the condition below.

- Applicable standard: EN 61800-5-1 :2007 / A1:2017 / A11:2021 (IEC61800-5-1 Ed.2.1)
- Pollution degree: 2
- Overvoltage category: 3
- The electronic power output short-circuit protection circuitry meets the requirements of IEC 60364-4-41:2005/AMD1 — Clause 411

When incorporating the inverter into a power drive system, take the following measures to comply with IEC61800-5-1 Ed.2.1.

(1) Installation and upstream protection devices

- Install the inverter into the enclosure with proper short circuit protective device (SCPD) in accordance with the table of prospective short-circuit current (Isc) rating shown in following table.
- Semiconductor fuses (gR, gS) are mandatory to comply with IEC61800-5-1 Ed2.1.

(2) Grounding

- Connect a dedicated wire to the grounding terminal on inverter.
- Ground each inverter directly when grounding multiple inverters.
- Refer to the table in [9. 1] of E6581975 to select a grounding wire size. At least 10 mm² (AWG 6) or two protective ground conductors with the cross section of the conductors supplying the power terminals may be required to meet standards limiting leakage current.

(3) Overload protection

- For overload protection of inverter, refer to [3.4] of E6581975.

(4) Motor overload protection

- For electronic motor thermal protection, refer to [3.4] of E6581975.
- Set the parameter F607: Motor 150% overload detection time to "300: Default setting" or less.

Prospective short-circuit current (Isc) rating table with semiconductor fuse

The rating of the short circuit protection devices in the table are maximum values. Smaller sizes can be used. Use the wire with the size described in [9.1] of E6581975.

Reference *1	Maximum input voltage (V)	Applicable motor (kW)	Max. IsC (kA)	SCPD rating (semiconductor fuse: IEC60269-4)			
				gR *2 690V		gS *2 690V	
				Rating (A)	Min. Size	Rating (A)	Min Size
VFNC3C-4004P	415	0.4	5	4	10x38	-	-
VFNC3C-4007P		0.75	5	6	10x38	-	-
VFNC3C-4015P		1.5	5	12.5	10x38	-	-
VFNC3C-4022P		2.2	5	16	10x38	-	-
VFNC3C-4037P		3.7	5	25	10x38	-	-
VFNC3C-4055P		5.5	22	40	14x51	-	-
VFNC3C-4075P		7.5	22	40	14x51	-	-
VFNC3C-4110P		11	22	-	-	63	000
VFNC3C-4150P		HD: 15	22	-	-	80	000
		ND: 18.5	5	-	-	80	000
VFNC3C-4150PL	HD: 15	22	-	-	80	000	
	ND: 18.5	5	-	-	80	000	
VFNC3C-4185P	HD: 18.5	22	-	-	100	1	
	ND: 22	5	-	-	100	1	
VFNC3C-4185PL	HD: 18.5	22	-	-	100	1	
	ND: 22	5	-	-	100	1	
VFNC3C-4220P	HD 22	22	-	-	125	00	
	ND: 30	5	-	-	125	00	
VFNC3C-4220PL	HD 22	22	-	-	125	00	
	ND: 30	5	-	-	125	00	

*1: Reference may be followed by any characters.

*2: Mersen is recommended supplier

Compliance with EMC Directive 2014/30/EU

This additional manual includes the additional information for [16] of E6581975 to comply with EMC Directive 2014/30/EU.

Products with EMC filter (VFNC3C-4xxxPL):

Conforming to both immunity and emission level part.

Products without EMC filter(VFNC3C-4xxxP):

These products cannot satisfy EMI requirement alone, but they can comply with the requirement by installing with the filter option shown in the table below

Reference *1	Carrier frequency (kHz)	EMC Filter	Conducted noise IEC61800-3 Category C3
			Length of motor cable (m)
VFNC3C-4004P	4	EMF4-4015B	25
VFNC3C-4007P	4	EMF4-4015B	25
VFNC3C-4015P	4	EMF4-4015B	25
VFNC3C-4022P	4	EMF4-4015B	25
VFNC3C-4037P	4	EMFS11-4025CZ	25
VFNC3C-4055P	4	EMFS11-4025CZ	25
VFNC3C-4075P	4	EMF4-4049E	25
VFNC3C-4110P	4	EMF4-4049E	25
VFNC3C-4150P	4	EMF4-4049E	25
VFNC3C-4185P	4	EMF3-4090F	25
VFNC3C-4220P	4	EMF3-4090F	25

*1: Reference may be followed by any characters.